


Lid open




Lid closed


Small Reveal shown for illustration purposes only.

Mounting to desk


For a desk thickness of 18-35mm




The fixing brackets must be removed before feeding the module into the desk.



Lower the Reveal module into the cut-out hole in the desk.^{1*}




Fix the brackets back in place, clamping the module to the desk.




If required the brackets can then be screwed to the desk.


Contents



Lid operation




Press down on the debossed triangle at the rear of the lid and guide it back gently.




Gently lift and guide the lid back to either partially open or fully closed.

Connecting to power

Connecting standard 3-pole connector




Plug the male 3-pole connector supplied as standard into a female powered connector.




Ensure the attached locking mechanism clicks into place on both connectors.

Disconnecting standard 3-pole connector




Use a suitable tool to release the locking mechanism.




Separate the connectors.

Connecting data/AV (if applicable)




Offer up the data/AV cable connectors to the related ports on the module.




Connect cables from the module to the source. Use suitable cable management for safety.

USB charging (if applicable)



Insert the USB connector from your device into the related port on the module.



Ensure the cable is securely connected.

Additional information

Safety

- Installation is to be carried out in accordance with relevant Health & Safety regulations and only to be carried out by a skilled or competent person.
- The product should be installed to comply with the relevant national standards and be inspected and tested prior to being put into service (in the UK BS 7671 Wiring Regulations or BS 6396 Office and Educational Systems Best Practice).
- Isolate the supply before installation or repositioning. Any locking mechanisms must be used and fully engaged.
- Incorrect use could lead to risk of electrocution.
- Connectors must not be engaged or disengaged when under load or live.
- Product to be used only for the intended purpose of distributing power and data in office and commercial environments.
- Do not misuse, dismantle or re-configure the product because doing so will invalidate the warranty.

Standards

- Refer to the Declaration of Conformity.

Further guidance

- Fuse replacement only to be carried out by a skilled or competent person.
- Should the supply cable need replacing, contact CMD.

Product care

- Clean using a dry cloth. No abrasives or solvents to be used on the product.
- Do not drop or expose to moisture.